

# Instruction

## 2.Setting a spool to a bonding machine

TANAKA DENSHI KOGYO K.K  
Quality Assurance Dpt.

① Set the spool removed from the case to the bonding machine.

① Set the spool removed from the case to the bonding machine.



① Set the spool removed from the case to the bonding machine.



① Set the spool removed from the case to the bonding machine.



① Set the spool removed from the case to the bonding machine.



① Set the spool removed from the case to the bonding machine.



① Set the spool removed from the case to the bonding machine.





① Set the spool removed from the case to the bonding machine.



① Set the spool removed from the case to the bonding machine.



① Set the spool removed from the case to the bonding machine.




① Set the spool removed from the case to the bonding machine.



① Set the spool removed from the case to the bonding machine.



① Set the spool removed from the case to the bonding machine.



①Set the spool removed from the case to the bonding machine.




①Set the spool removed from the case to the bonding machine.





②Take the wire gently from the notch to prevent it from loosening.



②Take the wire gently from the notch to prevent it from loosening.

②Take the wire gently from the notch to prevent it from loosening.



②Take the wire gently from the notch to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.





③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.




③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.







③Unwind the wire slowly to prevent it from loosening.




③Unwind the wire slowly to prevent it from loosening.




③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.




③Unwind the wire slowly to prevent it from loosening.

③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.





③Unwind the wire slowly to prevent it from loosening.



③Unwind the wire slowly to prevent it from loosening.